



PROCEDURE TO GET METER READING ON KYOCERA MACHINES

Machine Model Number Procedure to get Meter Reading

DP-1400

With the printer in the 'Ready' state press the 'ENTER/STATUS' button, a status page will print, the meter reading will be on this page in the bottom right corner

FS-720 / FS-820 /
FS-920

Hold down the button above the green symbol that looks like a C laying on it's back till the green and amber lights flash (approximately 5 seconds) and then let go. A 'STATUS PAGE' will print (the printer has to be in the 'READY STATE' to do this). The total 'Printed Pages (s)' will be under the 'Page Information'

FS-1000 / FS-1010 /
FS-1010+ / FS-1020D /
FS-1100 / FS-1120D /
FS-1300D / FS-1320D

Hold down the green 'GO' button for 5-10 seconds and then let go. The lights will flash and it will print a 'STATUS PAGE' (the printer has to be in the 'READY STATE' to do this).

FS-1016MFP

Press the 'MENU' button then use the ► button till the display says 'REPORTS', then press OK button. Press the ► button to 33 USAGE REPORT the press OK. It will print a usage report then return to ready.

FS-1028MFP /
FS-1028MFP/DP /
FS-1128MFP

Press the 'System Menu/Counter' button ('01 Report' will be highlighted). Press 'OK' button. ('01 Report Print' will be highlighted). Press 'OK' button. Press the ▼ button (under the OK button), so '02 Status Page' is highlighted. Press 'OK' button. Press button under 'YES' in the display. Report will print. The Total Count is to the right of Total (not to be confused with the Total Scanned at the bottom of the right column. Press button under 'Exit' in display.

FS-1035MFP /
FS-1135MFP

Press the 'System Menu/Counter' button ('01 Report' will be highlighted). Press 'OK' button. Press the ▼ button (under the OK button), so '02 Status Page' is highlighted. Press 'OK' button. Press button under 'YES' in the display. Report will print. The Total Count is to the right of Total (not to be confused with the Total Scanned at the bottom of the right column. Press button under 'Exit' in display.



GCG OI SERVICE

FS-3040MFP /
FS-3140MFP

Press the 'MENU' button then use the ▲▼ button till the display says 'COUNTER'. Press ► button and 'Printed Pages' and the total number of pages printed appears in the display. Press 'MENU' button to exit. To print out counter do following: Press 'Menu' button, Press ▲▼ button till 'Report Print' is in display, Press ► button, press ▼ button till 'Status Page' is in the display, press 'OK' button twice and 'Status Page' will print. Page count is in right hand column to the right of 'Printed Pages'.

FS-2000D / FS-3900D /
FS-4000DN

Press the 'MENU' button then use the ▲▼ button till the display says 'STATUS Page', then press ok/enter button twice to print status page with total page count. Or to display only press the 'MENU' button then use the ▲▼ button till the display says 'LIFE COUNTERS', press the ► 'Printed Pages' should be in the display along with the number of pages printed. Press the 'Menu' button to exit

FS-1350DN / FS-1370DN / FS-2020D / FS-3920DN /
FS4020DN

Press the 'MENU' button then the ▲▼ button till the display says 'COUNTER'. Press ► button and 'Printed Pages' and the total number of pages printed appears in the display. Press the 'MENU' button to exit. To print the counter do the following: Press the 'MENU' button then the ▲▼ button till the display says 'Report Print' is in the display, press 'OK' button twice and 'Status Page' is in the display, press 'OK' button twice and 'Status Page' will print. Press the 'MENU' button to exit. Page count is in the right hand column to the right of 'Printed Pages'.

FS-1900 / FS-1920 /
FS-3800 / FS-3820

Press the 'MENU' button then use the ▲▼ button till the display says 'STATUS Page', then press enter twice to print status page with total page count. Or to display only press the 'MENU' button then use the ▲▼ button till the display says 'LIFE COUNTERS', press the ► to see total counter in display, press 'MENU' button to exit.

FS-8000C / FS-9100 /
FS-9120 / FS-9130 /
FS-9500 / FS-9520 /
FS-9530

Press the 'MENU' button, then the ▲▼ buttons till 'STATUS' shows in the display, press the 'ENTER, button twice to print status page. Use the 'TOTAL PAGE' number under page information.



GCG OI SERVICE

FS-C5016N / FS-C5020N / FS-C5030N / FS-C8026N	Press the 'MENU' button, then the ▲▼ buttons till 'LIFE COUNTER' or 'PRINTED PAGES' shows in the display, press the ► button, then the ▲▼ till 'TOTAL PRINT' appears in the display. Press 'MENU' button to exit. To print 'STATUS PAGE' press the 'MENU' button, then the ▲▼ buttons till 'PRINT STATUS PAGE' is on the display, the 'ENTER' button twice and a 'STATUS PAGE' will print. Total count is under 'Page Information' and to the right of 'Printed Pages.'
FS-C5015N / FS-C5025N / FS-C8100DN	To print 'STATUS PAGE' press the 'MENU' button, then the ◆◆◆▼ buttons till 'PRINT STATUS PAGE' is on the display, the 'ENTER' button twice and a 'STATUS PAGE' will print. Total count is under 'Page Information' and to the right of 'Printed Pages.'
Taskalfa 250ci/ 300ci/500ci/300i/ 2550ci/2550ci/3050ci 3051ci/3550ci/3551ci 4550ci/4551ci/5550ci/ 5551ci/6550ci/6551ci 7550ci/7551ci/3550i/ 6500i/4500i/6501i/3501i	Press 'Counter' or 'System Menu/Counter' Button on the control panel. On the touch panel press 'Print Status Page'. It will ask for the confirmation. Click 'Yes'. The status page will be printed
